

Technical specifications


- Complies with USB v2.0/v1.1 norms
- Powered by USB port (2 USB ports required)
- No extra power needed
- Easy hardware installation
- Compatible with SLIM SATA drive
- Compatible with SLIM SATA writer
- Y-USB cable included for connection and power
- Compliant with most of SLIM SATA drive/writer

This enclosure is compliant with most of SLIM SATA drive/writer. However if the optical drive is not compliant, use another model or another brand.

Successfully tested with following models:


- SONY NEC AD-7590S / AD-7590A / AD-7630A
- LITEON DS-8A3S
- TEAC DVW28SR90

Front view



Front panel and ejection button of optical drive

Rear view



Use and FAQ

-If your system can't detect the optical drive, check that you have inserted the two USB plugs of the Y-USB cable. Check that your computer USB ports are functional and can provide enough power to the enclosure. Use the notebook external power supply.

-My drive/writer won't read nor burn: contact the customer technical support of the optical drive

- The burning speed depend on your writer limitations

- Place the enclosure on a flat surface

- Do not move; avoid any moving of the enclosure during burning session

- Do not connect USB peripheral during burning session

- In order to bund DVD or double layer DVD, it is recommended to use USB v2.0 port

- If you plan to not use your optical drive, please safely remove the enclosure and pull out the USB cable before keeping it in safe place.

- This enclosure is compliant with most of SLIM SATA drive/writer. However if the optical drive is not compliant, use another model or another brand